


## Licensing mobiLink for FF and PA

To use mobiLink for FOUNDATION Fieldbus and PROFIBUS PA you will need to activate a corresponding license. The license is optional and is not included in the standard delivery.

1. Go to the Softing Industrial website and click the icon in the upper right corner to register yourself or select this [My Softing Portal](#) link. When you are registered and logged in you are directed to the **My Softing** page.
2. Click **[Register License]**.
3. Enter the **license key** from your License Certificate in the license key input field. You will have received the License Certificate when you purchased the FOUNDATION Fieldbus or PROFIBUS PA license.
4. Open the mobiLink Manager you downloaded previously to read out the Host ID.
5. Select the **Licensing** tab.



6. Click **[Read]** for the mobiLink you wish to license. The Host ID is displayed.
7. Click **[Copy]**.
8. Paste the device ID into the **Device/Host ID** field of the MY Softing Portal page.

### Register License

Please enter your License Key and your Host ID. If you want to get notified in case of new releases, just check enable release info.

Activate License:

License Key

12345-ABCDE-67890-FGHIJ

Host ID

Enable Release Info

Register License

Cancel

9. Click **[Register License]**.  
A license file is generated.
10. Click **[Download]** to save the license file to your PC.
11. Switch to the mobiLink Manager application.
12. Select the mobiLink with the corresponding Device ID.
13. Click the icon to search for the license file on your PC and click **[Open]**.
14. Click **[Transfer License]**.  
The progress bar shows the installation status. You will be notified when the installation is completed.

## 5 Steps to activate the license

Purchase LRA – KK – 021973 (linkPlus FF) and/or LRA – LL – 021974 (linkPlus PA) to receive License-Key

Login to [MySofting](#) Portal. On your personal dashboard you will find your downloads, news and licenses. Go to [Register License]

Insert the License-Key and the Device ID to activate FF/PA. Use the mobiLink Manager to read Device ID of your mobiLink.

Click [Register License] in your Dashboard to create a License-File and download it to your Computer.

Switch back to mobiLink Manager. Select the mobiLink with the corresponding Device ID and transfer the License-File by clicking [Transfer License] to it.

**Purchase FF/PA**

**Login to MySofting**

**Insert FF/PA-Key  
+ Device Information**

**Download  
License-File**

**Transfer  
to mobiLink**